

WYZE CAM
OUTDOOR
QUICK START GUIDE

SETUP

- 1 Download the Wyze app and create an account.



- 2 Follow the Wyze app to set up the base station.




- 3 Follow the Wyze app to set up the camera.




- 4 Follow the instructions in the Wyze app to mount the camera.


The Wyze logo, consisting of the word "WYZE" in white capital letters on a teal rounded square background.




RIGHT



LEFT






BACK




TOP SURFACE

- 1 SYNC Button
- 2 MicroSD Slot
(MicroSD card not included)
- 3 Reset
- 4 USB Charging port
- 5 Power Input
- 6 LAN Port
- 7 Status Light




Removable Magnetic
Mounting Base


- 1 Light Sensor
- 2 Lens
- 3 Microphone
- 4 Removable Magnetic Mounting Base
- 5 On/Off Switch
USB Charging Port
- 6 Status Light
- 7 SYNC Button
- 8 MicroSD Slot
(MicroSD card not included)
- 9 Mounting Hole



Power Adapter



Camera Charging
USB Cable



Ethernet Cable





Screw Assembly



IN THE BOX

Wyze Cam Outdoor	x1
Base Station	x1
Base Station Power Adapter	x1
Base Station Ethernet Cable	x1
Camera Charging USB Cable	x1
Quick Start Guide	x1
Screw Assembly	x1

Wall Mounting







Ceiling Mounting










LIGHT INDICATIONS

Base Station

-  **Solid yellow light**
The device is powered on and initializing
-  **Flashing yellow & blue lights**
The device is pairing with the camera
-  **Flashing blue light**
The device is connecting to the network
-  **Solid blue light**
The device is working properly

Wyze Cam Outdoor

-  **Solid yellow light**
The device is powered on and initializing
-  **Flashing yellow & blue lights**
The device is pairing with the base station
-  **Flashing blue light**
The device is connecting to the network
-  **Solid blue light**
The device is working properly
-  **Flashing red light**
The device is charging
-  **Solid red light**
The device is fully charged
-  **No indicator light**
The device is powered off or sleeping

Precautions:

1. Prolonged direct sunlight can heat the inside of your camera past its maximum operating temperature of 122°F (50°C). Avoid directly sunlight where possible and only use your camera in environments within its operating temperature range: -4° to 122°F (-20° to 50°C).
2. To charge your camera, plug the included micro USB cable into the USB port on your base station and connect it to your camera. Or use a power adapter and cable that will provide 5V/2A power.

FCC Warning:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED RSS warning :

This device complies with ISED licence-exempt RSS standard (s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire d'interférence, et
- (2) l'appareil doit accepter toute interférence radioélectrique subi, même si l'interférence est susceptible d'en compromettre le fonctionnement.

ISED Radiation Exposure Statement:

This equipment complies with ISED RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet appareil est conforme aux limites d'exposition de rayonnement RF ISED établies pour un environnement non contrôlé.

Cet émetteur ne doit pas être co-implanté ou fonctionner en conjonction avec toute autre antenne ou transmetteur. Cet équipement doit être installé et utilisé avec une distance minimale de 20cm entre le radiateur & votre corps. Any changes or modifications not expressly approved

by the party responsible for compliance could void the user's authority to operate the equipment. Tous changements ou modifications non expressement approuvé par la partie responsable de la conformité peut annuler l'autorité de l'utilisateur a opérer l'équipement.

CONTAINS A LITHIUM ION BATTERY

Do not improperly dispose or discard. Lithium-ion batteries should be recycled. For information on how you can recycle the product at no cost, visit wyze.com/recycle.

NEED HELP?

Tutorial Videos

www.youtube.com/wyzelabs

Troubleshooting & FAQs

support.wyze.com

Join Our Community

<https://wyze.com/community>

Contact Us

<https://support.wyzecam.com/>

1-844-WYZECAM